



ADASEAL


our revolutionary power can dispensing system




Power Can Dispensing Instructions

- 

1. Make sure the surface is clean and dry, then snap off the tamper proof tab from nozzle, then remove overcap before dispensing.
- 

2. To open, turn nozzle anti clockwise for a quarter of a turn, this will open valve and raise lever, to dispense depress lever. When finished, turn nozzle clockwise which will close lever in original position. Replace overcap.
- 

3. If sealant has dried up in nozzle, with nozzle in closed position, swing lever over nozzle. Pull nozzle forward to remove, clean nozzle tip with paper clip or compressed air line.
- 

4. Relocate nozzle back over valve, with the two thick plastic fins pointing to the back hinge and front of lever. Swing lever back over nozzle to original position, slightly press the nozzle backwards towards the hinge, Use lever to firmly "click" nozzle back in position.

CAUTION: Unused sealant may irritate eyes, if this happens flush with water, call physician. Avoid prolonged skin contact, use adequate ventilation.

PRESSURIZED CONTAINER: Do not leave aerosol stored inside passenger compartment of vehicle, the aerosol is affected by direct sunlight, the aerosol should be stored in trunk of vehicle. The aerosol is affected by extreme high and cold temperatures.

Do not expose to temperatures exceeding 120F (50C) do not pierce or burn, even after use, do not remove rubber plug on base of can
KEEP AWAY FROM CHILDREN